

INDICATIONS FOR SETTING THE TIMER

DIGITAL AND THERMOSTAT

Generic information

Instructions for configuring the 3680W Digital Timer



1 - Set the time/day of the week:

Press and hold the Clock (CLOCK) button. With this button pressed, the Week button (WEEK) can be used to select the correct day, the correct time with the Hour button (HOUR) and Minute button (MIN). the right minute with the

2 - Schedule the intervals:

Press the (PROG) button once to select the first "ON" interval, you will see "1 ON" appear on the left of the LCD screen. This indicates that the first "ON" interval can be entered. Press the (WEEK) button to choose the required day or block of days, then set the required hour and minutes by pressing the (HOUR) and (MIN) buttons.

Press the button (CH1-3) repeatedly, until the arrow on the right of the LCD screen marks the desired connector. Press the (PROG) button to validate the entry.

Press the (ON/OFF) button to select the first "OFF" and "1 OFF" will appear on the left of the screen. This indicates that the first "OFF" can now be entered by pressing the buttons (WEEK, HOUR and MIN) as before. Press the (PROG) button to validate the entry.

Repeat to set the next desired "ON/OFF" intervals (up to 14).

When the programming of all the "ON/OFF" is finished, press the (CLOCK) button so that the timer screen will be ready to operate. It is possible to check all the programs by pressing the (PROG) button repeatedly: Each of the programs carried out will be displayed.

3 - Manual override of the timer:

It is possible to manually choose permanent "ON" (power is constant), permanent "OFF" (no power) and "AUTO" (timer is active) by pressing the button (ON/OFF) repeatedly. Each option will be displayed on the screen. Timer settings only work in "AUTO" mode.

4 - RESET button:

To reset the timer, both the hour/day and the "ON/OFF" intervals, press the button (RESET).

5- Standard configuration:

		Monday-Friday							
		05:00-08:00	08:00-11:00	11:00-13:00	13:00-15:00	15:00-16:00	16:00-18:00	18:00-20:00	20:00-05:00
CH1	WHERE								
	OFF								
CH2	WHERE								
	OFF								
CH3	WHERE								
	OFF								

Example to modify according to the needs of the center's timetable:

Step 1: Press “PROG” once to start the setup.

Step 2: Press the (ON/OFF) button to select the first “ON” interval (1 ON).

Step 2: Press "WEEK" to choose the block of days required.

Step 3: Set the hour and minutes with the “HOUR” and “MIN” buttons.

Step 4: Press the button (CH1-3) to select the desired channel.

Step 5: Press the (PROG) button to validate the entry.

Step 6: Press the (ON/OFF) button to select the first “OFF” interval (1 OFF).

Repeat steps 2 to 5 until you set the desired "ON/OFF" intervals (up to 14).

6 - Thermostat:

The cargo cabinet has an adjustable thermostat to trigger the cooling fans if necessary. The temperature can be regulated by means of a screw located at the back of the cart.

Wardrobe of 30



Cupboard of 12

